

# WOCA Pre-Colour

- for the staining of wood surfaces



Preparing today for tomorrow



- For a lighter surface, reduces yellowing process of the wood
- Requires subsequent treatment with oil, lacquer or soap
- Suitable for any type of wood
- Certified by IBR

## Product info

Container: 2,5 litre

Available in white, extra white, grey and black

Consumption: 8-10 m<sup>2</sup>/litre depending on wood type



## Application area

Pre-Colour is a water based stain for the priming of unfinished and sanded interior woodwork, such as floors, stairs, furniture and panels. Pre-Colour is available in white, extra white, grey and black.

## Result

Pre-Colour colours the wood surface and enhances the natural wood grain.

## Application

Apply Pre-Colour lengthwise the wood grain with a brush.

## After care

Requires a subsequent finishing treatment with oil, lacquer or soap.

**Attention:** Pre-Colour Black may only be treated with Oil-Lacquer!

## Maintenance and cleaning

According to the chosen finishing treatment.

# How to do...

## - WOCA Pre-Colour: Staining of wood surfaces



Preparing today for tomorrow



### Tools

Brush, plastic bucket and stick for stirring.

Clean tools with water and soap.

**Pre-Colour is a water-based stain used for the priming of unfinished or freshly sanded interior woodwork i.e. floors, stairs, furniture and panels. Pre-Colour enhances the wood grain prior to a protecting oil or lacquer finish. Pre-Colour may be used on all types of wood.**

**1** The unfinished woodwork must be well sanded, clean and dry before application of the Pre-Colour. Clean with 125 ml Wood Cleaner mixed with 5 litre water. Shake the container. Pour the Pre-Colour into a plastic bucket and stir regularly in order to obtain a uniform result.

**2** Apply the undiluted Pre-Colour in an even layer lengthwise onto the floor with a paint brush. Use at least 1 litre of Pre-Colour per 10 m<sup>2</sup>. On vertically mounted woodwork, apply from top to bottom. Clean tools in water.

When the wood is dry, clean with Wood Cleaner and leave to dry or alternatively use green pad under floor machine and subsequently vacuum clean the floor. Finish the floor with Wood Floor Oil, Master Oil, Colour Oil, High Solid Master Oil or Oil Lacquer.